

Page Part No	BCAC Part No	Nomenclature	Application	Notes
C14450-04	N/A	Voltage Sensing Unit	Jetstream 31	
C14450-05	N/A	Voltage Sensing Unit	Jetstream 31	
C1775	N/A	Flasher	BAE125	New Part Sales Only - No Repair
C475-01-001	N/A	Test Junction Box	Jetstream 31	
C9500-06-17A	N/A	Microphone Switch	BAE146	
C9500-07-18A	N/A	Microphone Switch	BAE146	
C9500-10-20A	N/A	Microphone Switch	Jetstream 31	
C9500-11-15A	N/A	Microphone Switch	Trident III	
C9500-11-21A	N/A	Microphone Switch	Jetstream 31	
C9500-12-19A	N/A	Microphone Switch	Jetstream 31	
C9850-85	N/A	Switch	Jetstream 31	New Part Sales Only - No Repair
D366-04-001	N/A	Emergency Power Supply	EMB120	
D428-01-001	60B80175-4	Engine Fire Shut-Off Switch	B747	
D434-01-001	60B80101-101	Flight Mode Annunciator	B747	
D434-02-001	60B80101-102	Flight Mode Annunciator	B747	
D434-03-001	60B80101-103	Flight Mode Annunciator	B747	
D434-05-001	60B80101-105	Flight Mode Annunciator	B747	
D434-06-001	60B80101-106	Flight Mode Annunciator	B747	
D434-07-001	60B80101-107	Flight Mode Annunciator	B747	
D434-21-001	60B80101-201	Flight Mode Annunciator	B747	
D434-22-001	60B80101-202	Flight Mode Annunciator	B747	
D434-23-001	60B80101-203	Flight Mode Annunciator	B747	
D434-32-001	10-62058-3	Flight Mode Annunciator	B737	
D434-33-001	10-62058-2	Flight Mode Annunciator	B737	
D434-35-001	10-62058-1	Flight Mode Annunciator	B737	
D434-36-001	10-62058-5	Flight Mode Annunciator	B737	
D434-51-001	60B80101-151	Flight Mode Annunciator	B747	
D434-56-001	10-62058-6	Auto-Flight Status Annunciator	B737	
D434-61-001	60B80101-301	Flight Mode Annunciator	B747	
D434-62-001	60B80101-302	Flight Mode Annunciator	B747	
D434-65-001	60B80101-305	Flight Mode Annunciator	B747	
D434-66-001	60B80101-306	Flight Mode Annunciator	B747	
D455-01-001	10-61318-10	Engine Fire Shut-Off Switch	B757/767	
D455-02-001	10-61318-11	Engine Fire Shut-Off Switch	B757/767	
D455-03-001	10-61318-12	Engine Fire Shut-Off Switch	B757/767	
D455-04-001	10-61318-13	Engine Fire Shut-Off Switch	B757/767	
D455-05-001	10-61318-14	Engine Fire Shut-Off Switch	B757/767	
D455-06-001	10-61318-15	Engine Fire Shut-Off Switch	B757/767	
D455-07-001	10-61318-16	Engine Fire Shut-Off Switch	B757/767	
D455-08-001	10-61318-17	Engine Fire Shut-Off Switch	B757/767	
D455-11-001	10-61318-23	Engine Fire Shut-Off Switch	B757/767	
D455-12-001	10-61318-24	Engine Fire Shut-Off Switch	B757/767	
D455-13-001	10-61318-25	Engine Fire Shut-Off Switch	B757/767	
D455-14-001	10-61318-26	Engine Fire Shut-Off Switch	B747	
D455-15-001	10-61318-41	Engine Fire Shut-Off Switch	B747	
D455-16-001	10-61318-42	Engine Fire Shut-Off Switch	B747	
D455-17-001	10-61318-43	Engine Fire Shut-Off Switch	B747	
D455-18-001	10-61318-44	Engine Fire Shut-Off Switch	B747	
D455-19-001	10-61318-45	Engine Fire Shut-Off Switch	B747	
D455-20-001	10-61318-46	Engine Fire Shut-Off Switch	B747	
D455-21-001	10-61318-47	Engine Fire Shut-Off Switch	B747	
D455-22-001	10-61318-48	Engine Fire Shut-Off Switch	B747	
D455-23-001	10-61318-49	Engine Fire Shut-Off Switch	B747	
D455-24-001	10-61318-51	Engine Fire Shut-Off Switch	B757/767	
D455-25-001	10-61318-52	Engine Fire Shut-Off Switch	B757/767	
D455-51-001	N/A	Engine Fire Shut-Off Switch	Fokker 50/60	
D455-52-001	N/A	Engine Fire Shut-Off Switch	Fokker 50/60	
D455-55-001	N/A	Engine Fire Shut-Off Switch	Fokker 70/100	
D455-56-001	N/A	Engine Fire Shut-Off Switch	Fokker 70/100	
D463-01-001	N/A	Central Warning Panel	Jetstream 31	
D463-02-001	N/A	Central Warning Panel	Jetstream 32	
D494-05-001	N/A	Landing Gear Control	Fokker 50	
D494-06-001	N/A	Landing Gear Control	EMB120	
D494-07-001	N/A	Landing Gear Control	Fokker 50	
D494-08-001	N/A	Landing Gear Control	Saab 340	
D494-10-001	N/A	Landing Gear Control	Saab 340	
D494-11-001	N/A	Landing Gear Control	EMB120	
D494-12-001	N/A	Landing Gear Control	Saab 340	
D494-13-001	N/A	Landing Gear Control	Fokker 50	

Page Part No	BCAC Part No	Nomenclature	Application	Notes
D494-14-001	N/A	Landing Gear Control	Fokker 50	
D496-01-001	N/A	Voltage Sensing Unit	Westland	
D524-01-001	N/A	Engine Fire Shut-Off Switch	EMB120	
D524-02-001	N/A	Engine Fire Shut-Off Switch	EMB120	
D533-01-001	10-61318-20	Engine Fire Shut-Off Switch	B737	
D533-02-001	10-61318-21	Engine Fire Shut-Off Switch	B737	
D533-03-001	10-61318-22	Engine Fire Shut-Off Switch	B737	
D533-04-001	10-61318-27	Engine Fire Shut-Off Switch	B737	
D533-05-001	10-61318-28	Engine Fire Shut-Off Switch	B737	
D533-06-001	10-61318-29	Engine Fire Shut-Off Switch	B737	
D533-07-001	10-61318-31	Engine Fire Shut-Off Switch	B737	
D533-08-001	10-61318-32	Engine Fire Shut-Off Switch	B737	
D533-53-001	N/A	Engine Fire Shut-Off Switch	Gulfstream V	
D533-54-001	N/A	Engine Fire Shut-Off Switch	Gulfstream V	
D552-01-001	N/A	De-Icing System Monitor	EMB120	
D701-02-001	N/A	Landing Gear Control	Saab 2000	
D710-02-001	N/A	Central Status Panel	BAE 146	
D717-02-001	S283W603-2	Emergency Power Supply	B737/757/767/777	
D724-03-001	S231W260-2	Landing Gear Control	B777	
D731-04-001	S231W263-4	Engine Fire Shut-Off Switch	B777	
D731-05-001	S231W263-5	Engine Fire Shut-Off Switch	B777	
D731-06-001	S231W263-6	Engine Fire Shut-Off Switch	B777	
D734-02-001	N/A	Emergency Power Supply	Falcon 50/2000	
D735-02-001	N/A	Cabin Light Unit	Saab 2000	
D735-05-001	N/A	Cabin Light Unit	Falcon 2000	
D738-01-001	S231W242-1	Engine Fuel Shut-Off Switch	B777	
D738-10-001	N/A	Engine Fuel Shut-Off Switch	Gulfstream V	
D741-11-001	N/A	Filter Box Assembly	ATP New Part Sales Only - No Repair	
D7720-01	N/A	Time Delay Unit	Jetstream 31	
D7720-02	N/A	Time Delay Unit	Jetstream 31	
D773-10-001	N/A	Solid State Ballast Unit	DC-9/MD80	
D773-11-001	N/A	Solid State Ballast Unit	DC-9/MD80	
D773-15-001	N/A	Solid State Ballast Unit	B747	
D773-20-001	N/A	Solid State Ballast Unit	DC-9/MD80	
D7800-XX	N/A	Annunciator Module	BAE125	
D796-32-001	N/A	Power Supply Unit	Various Retrofit	
D796-35-001	N/A	Power Supply Unit	Various Retrofit	
D813-10-001	N/A	Reading Light	Various Retrofit	
E530-03-001	N/A	Control Wheel	ATP New Part Sales Only - No Repair	
E530-04-001	N/A	Control Wheel	ATP New Part Sales Only - No Repair	
E547-03-001	N/A	Central Warning Panel	ATP	
E547-04-001	N/A	Central Warning Panel	ATP	
E548-XX-001	N/A	Central Warning Panel	BAE 146	
E650-01-001	N/A	Emergency Power Supply	MD-11	
E650-02-001	N/A	Emergency Power Supply	MD-11	
E650-03-001	N/A	Emergency Power Supply	MD-11	
E709-01-001	S417N514-1	Ceiling Light Unit	B737/757	
E709-03-001	S417N514-3	Ceiling Light Unit	B737/757	
E709-04-001	S417N514-4	Ceiling Light Unit	B737/757	
LAST ITEM				